


dacor

LET THE SHOW BEGIN

DHD48M978W S/M



DHD48M987



DHD48M987

REFERENCE#	PART NUMBER	DESCRIPTION
1	Not Serviceable	ASSY, 48X18IN CANOPY
2	702851	ASSY, 48IN LINER
3	702423	ASSY, CANOPY, MTG BRKT
4	703005	WELDMENT, INTERIOR PANEL
5	702873	ASSY, REAR LINER, 48"
6	702869	WELDMENT, 48IN GREASE TRAY
7	702718	ASSEMBLY, BLOWER
8	702493	ASSY, TERMINAL BLOCK PLATE
9	702967-01	ASSY, CONTROLLER
10	110493	WIRES, HOOD GROUND
11	702855	ASSEMBLY, CONTROL BRACKET
12	110345	HARNESS, 4 LIGHT LED WIRE
13	109072	HARNESS, MAIN WIRE, 2-FAN
14	109114	FRAME, SIDE
15	101613	COLLAR, DAMPER
16	110158-01	TRIM, 48IN, LH
17	110158-02	TRIM, 48IN, RH
18	83308	6-32 KEPS NUT
19	83263	SCREW, PHILL, ROUND WASHER, HD.
20	83534	SCREW, #8 X .375, ENAMEL PANEL
21	102373	SCREW, #8-18 X 1/4"
22	83167	CLAMP, CABLE 3/4"
23	83056	BUSHING HEYCO SB-875-11
24	83334	STARWASHER, #8
25	83035	NUT, WING, #10-24
26	83530	SCREW, PHIL. PAN HD, 4-40 X .625 LG
27	83531	NUT, HEX, KEPS 4-40
28	83001	SCREW, PHIL PAN HD, 8-32
29	102403	SCREW, SLOT HEX, PHIL
30	102402	CUP WASHER
31	110301	THERMISTOR
32	109253	LIGHT, LED
33	109109	KNOB, BAFFLE
34	109328	SCREW 8-32 X 5/16" PHIL PAN HD
35	83340	#10 LOCK WASHER
36	702495	WELDMENT, BAFFLE
37	702848	CONTROL, NK9900
38	109355	TRIM, LAMP, HOOD
39	101624	LAMP HOLDER