


DTG36M955FS

DTG36M955FS

ASSY BODY

dacor




Assy Body Parts List

Reference #	Dacor Part #	Description	SA/SNA
1	111765	SCREW-MACHINE	SA
2	111821	HOLDER	SA
3		SPRING ETC	SNA
4		HOLDER KREFERENCE #B	SNA
5	111827	HOLDER FILTER	SA
6		COVER-POWER CORD	SNA
7		COVER PCB	SNA
8	112043	GASKET	SA
9		COVER WIRE	SNA
10		RUBBER	SNA
11	111884	RUBBER	SA
12	111883	RUBBER	SA
13	111885	RUBBER	SA
14	111891	ASSY BURNER HEAD-MID(R)	SA
15	111892	ASSY BURNER HEAD-MID(SR)	SA
16	111939	ASSY KREFERENCE #B	SA
17		ASSY HOLDER PCB-WIFI	SNA
17-1		W-LAN MODULE	SNA
17-2		ASSY MODULE	SA
17-3		HOLDER PCB-WIFI	SNA
18		ASSY CASE BURNER	SNA
18-1		CABLE CLAMP	SNA
18-2		CASE BURNER	SNA
18-3		HOLDER TUBE-A	SNA
18-4		HOLDER TUBE-B	SNA
18-5	111749	COVER WIRE	SA
18-6	112028	ASSY WIRE HARNESS-COOKTOP	SA
18-7		BRACKET BURNER	SNA
18-8		ASSY MODULE SPARK	SNA
18-9		HOLDER PCB-MAIN	SNA
19	111944	ASSY FRAME COOK TOP	SA
20		ASSY HOLDER PCB	SNA
20-1	111762	BLUETOOTH MODULE	SA
20-2	111823	HOLDER PCB-BLUETOOTH	SA

Assy Body Parts List

Reference #	Dacor Part #	Description	SA/SNA
20-3	111851	COVER PCB-BLUETOOTH	SA
20-4	112027	ASSY WIRE HARNESS- COMM	SA
21		CBF-POWER CORD	SNA
22	111771	ASSY MODULE	SA
23	112037	ASSY MODULE	SA
24	111794	ASSY PCB EEPROM	SA
25	111982	ASSY ELECTRODE-DUAL	SA
26	112018	ASSY ELECTRODE-SINGLE	SA
27		ASSY ELECTRODE-SINGLE	SNA
28		ASSY ELECTRODE-SINGLE	SNA
29	112022	ASSY SWITCH IGNITION	SA
29-1		ASSY MODULE	SA
29-2	111783	ASSY MODULE	SA
29-3	112020	ASSY SWITCH IGNITION- SUB	SA
30	112024	ASSY WIRE HARNESS- MAIN	SA
31	112026	ASSY WIRE HARNESS- DC SIGNAL	SA
32	111822	BRACKET GUIDE	SA
33	111908	ASSY VALVE-REGULATOR	SA


2. ASSY COOKTOP



Assy Cooktop Parts List

Reference #	Dacor Part #	Description	SA/SNA
1		ASSY COOKTOP	SNA
1-1		ASSY VALVE MANIFOLD	SNA
1-1-1		BRACKET BURNER-DUAL	SNA
1-1-2	111842	BURNER CUP-SINGLE	SA
1-1-3	111843	BURNER CUP-SINGLE	SA
1-1-4	111844	BURNER CUP-DOUBLE	SA
1-1-5	111945	ASSY VALVE DUAL	SA
1-1-6	111946	ASSY VALVE DUAL	SA
1-1-7		ASSY VALVE MANIFOLD	SNA
1-1-7-1		BRACKET PIPE	SNA
1-1-7-2		BRACKET GUIDE	SNA
1-1-7-3		BRACKET SUPPORTER	SNA
1-1-8	111955	ASSY TUBE	SA
1-1-9	111956	ASSY TUBE	SA
1-1-10	111957	ASSY TUBE-RIGHT FRONT	SA
1-1-11	111958	ASSY TUBE-RIGHT FRONT	SA
1-1-12	111959	ASSY TUBE-RIGHT REAR	SA
1-1-13	111960	ASSY TUBE-RIGHT REAR	SA
1-1-14	111961	ASSY TUBE-LEFT REAR	SA
1-1-15	111962	ASSY TUBE-LEFT REAR	SA
1-1-16	111963	ASSY TUBE	SA
1-1-17	111964	ASSY TUBE	SA
1-2		GASKET	SNA

3. ASSY ACCESSORY



Assy Accessory Parts List

Reference #	Dacor Part #	Description	SA/SNA
1		ASSY ACCESSORY PARTS	SNA
1-1	111838	BURNER HEAD-SINGLE	SA
1-2	111839	BURNER HEAD-SINGLE	SA
1-3	111840	BURNER HEAD-DOUBLE	SA
1-4	111841	BURNER HEAD-DOUBLE	SA
1-5	112015	ASSY REFERENCE #ZZLE KIT	SA
1-5-1		REFERENCE #ZZLE DUAL	SNA
1-5-2		REFERENCE #ZZLE DUAL	SNA
1-5-3	111845	REFERENCE #ZZLE-SEMI RAPID LP	SA
1-5-4	111846	REFERENCE #ZZLE-SEMI RAPID LP	SA
1-5-5	111847	REFERENCE #ZZLE-RAPID LP	SA
1-5-6	111848	REFERENCE #ZZLE-RAPID LP	SA
1-6	112033	ASSY PACKING GRATE-CENTER	SA
1-7	112034	ASSY PACKING GRATE-SIDE	SA
1-8	112036	ASSY PACKING-CAP SUB	SA
1-8-1	110431-02	BURNER CAP AUX	SA
1-8-2	111835	BURNER CAP-DOUBLE	SA
1-8-3	111836	BURNER CAP-SINGLE	SA
1-8-4	111837	BURNER CAP-SINGLE	SA
1-8-5	111831	BURNER CAP-SINGLE	SA
1-8-6	111832	BURNER CAP-SINGLE	SA
1-8-7	111833	BURNER CAP-DOUBLE	SA
1-8-8	110431-01	BURNER CAP-DOUBLE	SA
1-8-9	111888	PACKING BURNER CAP-BRASS	SA
1-8-10	111890	PACKING BURNER CAP-BOX	SA
1-8-11		PACKING BURNER CAP	SNA