


dacor

LET THE SHOW BEGIN


DTHP3010



HOOD ASSY.



CONTROL PANEL ASSY.



Reference	PART NUMBER	DESCRIPTION	NOTES
1	Not Serviceable	ASSY, 30X10IN CANOPY	
2	702491-02	ASSY, FAN W2E200-HH86-01	
3	702446-02	ASSY, 30IN LINER, DTHP	
4	702487	WELDMENT, 30X10IN INTERIOR PNL	
5	702448	ASSY, 30IN REAR LINER	
6	702449	WELDMENT, 30IN GREASE TRAY	
7	702492-01	ASSY, TERMINAL BLOCK PLATE	
8	702714	WELDMENT, COLAR DAMPER	
9	109154	FRAME, SIDE	
10	109141-01	TRIM, 30IN, LH	
11	109141-02	TRIM, 30IN, RH	
12	81132	FOAM TAPE, URETHANE	
13	72685	HARNESS, SINGLE FAN	
14	109278	HARNESS, MAIN WIRE, 1-FAN	
15	83263	SCREW, PHILL, ROUND WASHER, HD.	
16	83534	SCREW, #8 X .375, ENAMEL PANEL	
17	102373	SCREW, #8-18 X 1/4"	
18	83056	BUSHING HEYCO SB-875-11	
19	83308	6-32 KEPS NUT	
20	83334	STARWASHER, #8	
21	83035	NUT, WING, #10-24	
22	83578	BUMPER, RUBBER, SNAP-IN	
23	92348	LAMP, HALOGEN, 75W	
24	702490	FILTER, MESH	
25	109165	FRAME, FRONT, FILTER	P/O 702490
26	109166	FRAME, REAR, FILTER	P/O 702490
27	109164	MESH, FILTER	P/O 702490
28	83505	SCREW, #8x3/8, TYPE A	P/O 702490
29	83340	#10 LOCK WASHER	P/O 702490
30	109328	SCREW, 8-32 x 5/16" PHIL PAN HD	P/O 702490
31	109109	KNOB, BAFFLE	P/O 702490
32	702512	ASSY, CTRL PANEL, DTHP	P/O 702446-02
33	109167	KNOB, CTRL	P/O 702512
34	72757	ASY, FAN SPEED CTRL	P/O 702512
35	72756	ASY, LAMP DIMMER	P/O 702512
36	107578	SCREW BP, PHIL, FLT HD, TYP 1	P/O 702512
37	101624	LAMP HOLDER	P/O 702512
38	109355	TRIM, LAMP, HOODS	P/O 702512