


dacor

LET THE SHOW BEGIN


DTHP3018



HOOD ASSY.



CONTROL PANEL



DTHP3018

Ref#	PART NUMBER	DESCRIPTION	NOTES
1	Not Serviceable	ASSY, 30X18IN CANOPY	
2	702423	ASSY, CANOPY, MTG BRKT	
3	702491-02	ASSY, FAN W2E200-HH86-01	
4	702446-02	ASSY, 30IN LINER, DTHP	
5	702508	WELD, INTER PANEL	
6	702448	ASSY, 30IN REAR LINER	
7	702449	WELDMENT, 30IN GREASE TRAY	
8	702492-01	ASSY, TERMINAL BLOCK PLATE	
9	702714	WELDMENT, COLAR DAMPER	
10	109114	FRAME, SIDE	
11	109141-01	TRIM, 30IN, LH	
12	109141-02	TRIM, 30IN, RH	
13	81132	FOAM TAPE, URETHANE	
14	72685	HARNESS, SINGLE FAN	
15	109278	HARNESS, MAIN WIRE, 1-FAN	
16	83263	SCREW, PHILL, ROUND WASHER, HD.	
17	83534	SCREW, #8 X .375, ENAMEL PANEL	
18	102373	SCREW, #8-18 X 1/4"	
19	83056	BUSHING HEYCO SB-875-11	
20	83308	6-32 KEPS NUT	
21	83334	STARWASHER, #8	
22	83035	NUT, WING, #10-24	
23	83578	BUMPER, RUBBER, SNAP-IN	
24	92348	LAMP, HALOGEN, 75W	
25	702490	FILTER, MESH	
26	109165	FRAME, FRONT, FILTER	P/O 702490
27	109166	FRAME, REAR, FILTER	P/O 702490
28	109164	MESH, FILTER	P/O 702490
29	83505	SCREW, #8x3/8, TYPE A	P/O 702490
30	83340	#10 LOCK WASHER	P/O 702490
31	109328	SCREW, 8-32 x 5/16" PHIL PAN HD	P/O 702490
32	109109	KNOB, BAFFLE	P/O 702490
33	702512	ASSY, CTRL PANEL, DTHP	P/O 702446-02
34	109167	KNOB, CTRL	P/O 702512
35	72757	ASY, FAN SPEED CTRL	P/O 702512
36	72756	ASY, LAMP DIMMER	P/O 702512
37	107578	SCREW BP, PHIL, FLT HD, TYP 1	P/O 702512
38	101624	LAMP HOLDER	P/O 702512
39	109355	TRIM, LAMP, HOODS	P/O 702512

[Type here]

[Type here]

[Type here]