

# **dacor**®

The Life of the Kitchen.®

## **PARTS CATALOG**


### **RO130/ROV130 Wall Oven**

<b>Page #</b>	<b>Description</b>
<b>2</b>	<b>Door Assembly</b>
<b>3</b>	<b>Chassis Assembly</b>
<b>4</b>	<b>Control Panel</b>
<b>5</b>	<b>Sub-Chassis Electrical Components</b>
<b>6</b>	<b>Oven Cell Components</b>
<b>7</b>	<b>Miscellaneous Components</b>

Revised 04-09-2015

# RO130/ROV130 Wall Oven Door Assembly

External handle version shown.




Item	Part #	Description
	701475-01	COMPLETE DOOR ASSEMBLY, RO130B
	701698-03	COMPLETE DOOR ASSEMBLY, RO130FS
	701426-01	COMPLETE DOOR ASSEMBLY, RO130S
	701788-01	COMPLETE DOOR ASSEMBLY, RO130W
	701503-01	COMPLETE DOOR ASSEMBLY, ROV130B
<b>1</b>	701474	ASSEMBLY, DOOR SKIN, RO130B
	701697	ASSEMBLY, DOOR SKIN, RO130FS
	701427-01	ASSEMBLY, DOOR SKIN, RO130S
	701789	ASSEMBLY, DOOR SKIN, RO130W
	701759	ASSEMBLY, DOOR SKIN, ROV130B
<b>2</b>	13659-001	ASSEMBLY, DOOR HANDLE, STAINLESS
	13659-019	ASSEMBLY, DOOR HANDLE, BLACK
	13659-021	ASSEMBLY, DOOR HANDLE, WHITE
<b>3</b>	72510CH	LOGO, DACOR, 3", CHROME
<b>4</b>	107221B	HEAT SHIELD
<b>5</b>	105353	INSULATION, SIDE DOOR

Item	Part #	Description
<b>6</b>	105352	INSULATION, TOP DOOR
<b>7</b>	72711	HINGE, LEFT
<b>8</b>	72710	HINGE, RIGHT
<b>9</b>	72968	WINDOW PACK
<b>10</b>	100015	GASKET, WINDOW PACK
<b>11</b>	701428-01 <sup>1</sup>	ASSEMBLY, DOOR LINER, RO130S
	701428-02 <sup>1</sup>	ASSEMBLY, DOOR LINER, RO130B, RO130W, ROV130B
	701428-05 <sup>1</sup>	ASSEMBLY, DOOR LINER, RO130FS
<b>12</b>	701430BP <sup>2</sup>	DOOR LINER <sup>2</sup>
<b>13</b>	100026	SCREW, #10-32 X 2.0, TORX
<b>14</b>	105510-01	HINGE BRACKET COVER, RIGHT
<b>15</b>	105510-02	HINGE BRACKET COVER, LEFT
<b>16</b>	83263	SCREW, PHIL TRS, #8 X 3/8, BLACK

<sup>1</sup> Pre-assembled, includes door liner, window pack with gasket, hinges, hinge covers, all insulation, heat shields and air deflectors.

<sup>2</sup> Door liner alone.

# RO130/ROV130 Wall Oven Chassis Assembly



See page 5 for wiring harness.

Item	Part #	Description
1 <sup>1</sup>	-	ASSY, BEZEL/CAPACITIVE TOUCH <sup>1</sup>
2 <sup>2</sup>	-	SUB-CHASSIS <sup>2</sup>
3	82347	FAN, COOLING
4	105316	TOP, REAR
5	105315	TOP, LEFT SIDE
6	105314	TOP, RIGHT SIDE
7	105318	TOP RIGHT REAR CORNER
8	105319	TOP, FRONT SUPPORT
9	105324	COVER, TOP
10	105363	EMBOSS, COOLING FAN
11	105320	COVER, COOLING FAN
12	105357B	INTAKE GRILL
13	105350B	EXHAUST GRILL (BLACK)
	105350W	EXHAUST GRILL (WHITE)
	107735	EXHAUST GRILL (STAINLESS)
14	105326	DUCT, REAR
15	105325	COVER, BACK


Item	Part #	Description
16	82195	1/2" 90° SQUEEZE CONNECTOR
17	26420	CONDUIT, 1/2" FLEX, CUT 60
18	105328-02B	TRIM POST, LEFT
19	105328-01B	TRIM POST, RIGHT
20	105462	HEAT SHIELD, DUCT
21	105478	COVER, MEAT PROBE WIRE
22	105330	DUCT, SMOKE ELIMINATOR
23	100090	LATCH, CLASSIC WALL OVEN
24	701423	ASSY, EXHAUST PLATE
25	83133	BUSHING, 1/2", RED
26	92191-02	BUSHING, SPLIT 1.00"
27	92191-03	BUSHING, SPLIT 1.375"
28	92191-01	BUSHING, SPLIT .75"
29	83709	SCREW, #8 X 1/2", TORX, BLK OXIDE
30	83708	SCREW, TRX WFR HD, #8 X 1/2"
31	83710	SCREW, WASHER HD #8 X 3/8"
32	92321	HIGH LIMIT SWITCH
33	105366	DOOR GASKET
34	105468BP	DOOR GASKET COVER

<sup>1</sup> See page 4 for individual components

<sup>2</sup> See page 5 for individual components




# RO130/ROV130 Wall Oven Control Panel Assembly



Item		Description
1	701476-01*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, RO130B*
	701431-01*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, RO130S*
	701504-01*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, ROV130B*
2	105335	CONTROL BOARD, RO130/ROV130
3	105334	CONTROL BOARD BASE
4	105486	SCREW, 6-19 X 3/8"
5	105655	RIBBON CABLE


\* Includes items 2, 3 and 4 (6 each).

# RO130/ROV130 Sub-Chassis Electrical Components



Item	Part #	Description
1	102377	RELAY BOARD, RO130/ROV130
2	105448	WIRING HARNESS, POWER BOARD
3	83538	PCB SUPPORT, NYLON
4	62808	TRANSFORMER, RO130/ROV130
5	83023	SCREW, SLOT HWH #10 X 3/8 THD
6	105349	WIRING HARNESS, MAIN
7	83009	NUT, KEPS, #10-24
8	92191-02	BUSHING, SPLIT 1.0"
-	105729	WIRING HARNESS EXTENSION RELAY BOARD/TOUCH PAN (not shown)

# RO130/ROV130 Wall Oven Cell Components




Item	Part #	Description
1	106898	BAKE ELEMENT
2	82377	CONVECTION ELEMENT
3	105329BP	CONVECTION BAFFLE
4	701529 <sup>1</sup>	BROIL ASSEMBLY <sup>1</sup>
5	72752	SENSOR, TEMPERATURE
6	92398	ASSEMBLY, HALOGEN LIGHT, 12V, 20W
7	100429	BULB, HALOGEN, 12V, 20W
8	72755	SMOKE ELIMINATOR
9	72348	HINGE RECEPTACLE
10	106991	RACK SUPPORT

<sup>1</sup> Broil assembly includes element, glass and frame

Item	Part #	Description
11	700633 <sup>2</sup>	KIT, CONVECTION FAN <sup>2</sup>
12	82891	FILTER, CONVECTION
13	101511	CONVECTION FAN BLADE
14	83708	SCREW, TORX WAFER HEAD, #8 X 1/2"
15	72717	MEAT PROBE SOCKET
16	102137	HEX NUT, CONVECTION FAN
17	102136	WASHER, CONVECTION FAN
18	83661	SCREW, WASHER HEAD #8 X 3/8
19	83379	SCREW, #8-1/2 THREAD TYPE A

<sup>2</sup> Kit includes motor, fan blade, fan blade washer and mounting nut.

# RO130/ROV130 Wall Oven Miscellaneous Parts



Item	Part #	Description
1	701464	OVEN RACK, GLIDERACK TYPE
2	100429	BULB, HALOGEN, 12 V, 20 W
3	92398	ASSEMBLY, LIGHT, HALOGEN, 12V, 20W
4	72723	MEAT PROBE
5	100852	STAINLESS STEEL CLEANER
6	106992	OVEN RACK, STANDARD
7	82106	PORCELAIN GRILL
8	82107	PORCELAIN PAN